

Warranty Standard

Warranty Standard

Warranty period	The warranty period shall be 24 months from the date of shipment, limited to new units.
Warranty Condition	In the event that the Product fails during the Warranty Period when it is properly installed and combined with other equipment, maintained as specified in the maintenance manual, and properly operated as specified in the catalog or as otherwise agreed upon, the Seller will provide, at its sole discretion, appropriate repair or replacement of the Product free of charge, except as stipulated in the "Warranty Exclusions" as described below. However, if the Product is combined with other equipment, the Seller shall not indemnify the Buyer from any costs of removal or reinstallation of the Product from or to the appropriate equipment, or other incidental costs (such as construction cost and cost of transportation) related thereto, any lost opportunity, any profit loss or other consequential damages incurred by the Buyer.
Warranty Exclusions	<p>Notwithstanding the above warranty, the following shall be warranty exclusions:</p> <ol style="list-style-type: none"> 1. Any failure attributable to improper installation of the Product or improper combination with other equipment 2. Any failure that may occur due to the cause that the Product is maintained in an insufficient manner and handled in an incorrect manner (for example, if it is not stored as specified in the storage procedure manual established by the Seller) 3. Any failure attributable to any operation not conforming to the specification, or any other operation conditions or state unknowable to the Seller, or any failure attributable to use of a lubricant other than the Seller-recommended ones 4. Any failure attributable to a problem or special specification of the equipment with which the Buyer combined the Product 5. Any failure attributable to a modification or restructuring made, by the Buyer, to the Product 6. Any failure attributable to a problem of a component or part supplied from or designated by the Buyer 7. Any failure attributable to an earthquake, fire, flood, salt damage, gaseous damage, lightning strike, or any other reasons beyond the control of the Seller 8. Warranty concerning a naturally worn and torn , abraded, or degraded consumable part (such as a bearing or oil seal) that may result after normal use of the Product 9. Any failure that is caused for any of the other reasons not attributable to the responsibilities of the Seller

Warning

SAFETY PRECAUTIONS

- Observe safety rules for installation site and equipment strictly (Industrial Safety and Health Law, Technical Standard for Electric Facilities, Extension Rules, Plant Explosion guidelines, Building Standards Law, etc.)
- Read the maintenance manual carefully before use. Request one from the distributor you purchased from or our sales department if it is not handy. The maintenance manual must reach the actual user.
- Select an appropriate product to match the operating environment and application.
- Install protective equipment on the machine side when the machine is used for passenger transportation and elevators, escalators, and dumb waiters.
- Use a flameproof type motor for use in explosive environment. Select a flameproof type motor with appropriate specifications sufficient for hazardous locations.
- Either mount a control filter or a reactor on the inverter side or use a sufficiently insulated motor when a 400V class inverter is used to drive motor. Install an oil pan or other devices to prevent oil or grease leakage, just in case of failure or termination of service life, for oil-sensitive applications such as food processing and clean rooms.